4. Remove the protective film from the dome. Softly wipe the dome with lens tissue or a microfiber cloth to remove any dust or smudges left from the installation process.

When rotating or tilting the camera module, make sure the final

Assemble the dome cover over the camera body. Align the dome and bottom

Mounting template

position aligns with the IR LEDs at the base.

case to match the position of the microphone output's hole.

NOTE: Be careful not to alter the direction of the camera module.

В

Use the diagram below to connect power, network and external devices such as

Network

STEP 5 - MANAGING THE SD CARD (OPTIONAL) 1. Locate the SD card slot at the base of the camera module.

2. Insert a class 10 SD/SDHC/SDXC card into the SD card slot by pressing the SD card

3. Press the card inward until it clicks to release from the card slot, and then pull it out

DI COM

DO1 (N.O.)

DOI COM

Alarm Out

Audio Out

Sky Blue

Gray + Do

Alarm In

audio input and output, alarm and sensors to the camera.

Power

STEP 4 - CABLING

until it clicks.

from the slot.

NOTE: Maximum SD Card size supported: Up to 1TB micro SD / FAT32. When inserting the SD card into the card slot, the SD card's contacts should be facing upward, as shown in the diagram. STEP 6 - DW® IP FINDER™ Use the DW IP Finder software to scan the network and detect all MEGApix® cameras, set the camera's network settings or access the camera's web client. Camera name -Select network to scan Filter results Scan network how/hide thumbnail view Refresh thumbnail view Open IP configuration settings Refresh thumbnail view— Bulk IP assignment Bulk codec assignment ulk date/time assignment ulk password assignment Ping camera information Firmware upgrade Camera's name, IP and W-DIGITAL WATCHDOG Network Setup 1. To install the DW IP Finder, go to: http://www.digital-watchdog.com 2. Enter "DW IP Finder" on the search box at the top of the page. 3. Go to the "Software" tab on the DW IP Finder page to download and install the installation file. 4. Open the DW IP Finder and click 'Scan Devices.' It will scan the selected network for all supported devices and list the results in the table. During the scan, the DW® logo will turn gray. 5. When connecting to the camera for the first time, a password must be set. Bulk Password Assignment a. Check the box next to the camera in the IP Finder's search results. You can select Current Account New multiple cameras. b. Click "Bulk Password Assign" on the left. Enter admin/admin for the current username and password. Enter a new username and password to the right.

DWC-MF2Wi4T 00:0D:F1:21:66:92 192.168.10.159

W Camera Settings

Camera Name

MAC Address

O DHCP

Static IP

Netmask

Gateway

Camera Account Username admin Password •••••••

DNS

IP Address

X

DWC-MF4Wi6C6

00:0D:F1:2B:7B:CB

192.168.21 .144

255.255.255.0

192.168.21 .1 8 .8 .8 .8

Passwords must have a minimum eight (8) characters and at least four (4) combinations of uppercase and lowercase

6. Select a camera from the list by double-

clicking on the camera's name or clicking on the 'Click' button. The pop-up window will

show the camera's current network settings.

Admin users can adjust the settings as needed. The camera's network settings are

To access the camera's web page, click on

settings, enter the username and password

of the camera's admin account and click 'Apply.'

8. To save changes made to the camera's

set to DHCP by default.

the 'Website' button.

DHCP server.

Rev: 04/24

and DNS information.

your network's router.

STEP 7 - WEB VIEWER

letters, numbers and special characters. Passwords cannot contain the user ID. d. Click "change" to apply all changes.

1 Select 'DHCP' for the camera to automatically receive its IP address from the

🚺 Select 'Static' to manually enter the camera's IP address, (Sub) Netmask, Gateway

🌓 To access the camera from an external network, port forwarding must be set in

1 The camera's IP must be set to static if connecting to Spectrum® IPVMS.

(1) Contact your network administrator for more information.

The GUI display may differ depending on the camera model. Find the camera using the DW IP Finder. 2. Double-click on the camera's view in the results table. Press the 'View Camera Website'. 4. Enter the camera's username and password you set up in the DW IP Finder. If you did not set up a new username and password, a message will direct you to set up a new password for the camera to view the video. http://192.168.10.159/ - IP Camera - Internet Explorer Change admin's password Password Retype Password Password Hint [Type the Password] Password requirement: minimum 8 characters with at least three combinations of uppercase letters, lowercase letters, numbers and special characters. Acceptable special characters are; $\sim 1.5 \ () - |\{\}[]; .?/$

CHANGE LATER CHANGE PASSWORD

Copyright @ Digital Watchdog. All rights reserved. Specifications and pricing are subject to change without notice.

NOTE: Please see the full product manual for web viewer setup, functions and camera settings options. This products is covered by one or more claims of the HEVC Patents listed at patentlist.accessadvance.com. NOTE: Tel: +1 (866) 446-3595 / (813) 888-9555 digital-watchdog.com Technical Support Hours: 9:00AM - 8:00PM EST, Monday through Friday