



4MP model 2.1MP/1080p model DWC-MB75Wi4TWDMP DWC-MB72Wi4TWDMP



Quick Setup and Download Guides		1 set	Screws and Plastic Anchors - 4pcs		1 set
Mounting Template	(0)	1	Star Wrench (T-20)		1
Waterproof Cap and Rubber Rings (Black: Ø0.15" (Ø4mm), White: Ø0.19" (Ø5mm))		1 set			
NOTE: Download all your support materials and tools in one place 1. Go to: http://www.digital-watchdog.com/resources 2. Search your product by entering the part number in the 'Search by Product' search bar. Results for applicable part numbers will populate automatically based on the					


WHAT'S IN THE BOX

that the user read the entire instruction manual for complete and proper installation and usage.

part number you enter.
3. Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results

- SAFETY AND WARNING INFORMATION
- Read through this Installation Guide carefully before installing the product. Keep the Installation Guide for future reference. See the user manual for more information on the product correctly to avoid danger or property loss. Warnings: Serious injury or death may occur if any of the warnings are neglected.

 Cautions: Injury or equipment damage may occur if any of the cautions are neglected.



WARNING

3. 4. 5.

10.

10. 11.

IRNING

In the use of the product, you must be strict compliance with the electrical safety regulations of the nation and region. When the product is mounted on a wall or ceiling, the device shall be firmly fixed.

Be sure to use only the standard adapter specified in the specification sheet. Using any other adapter could cause fire, electrical shock, or damage to the product.

Make sure the power supply voltage is correct before using the camera. Incorrectly connecting the power supply or replacing the battery may cause an explosion, fire, electric shock, or damage to the product.

Do not connect multiple cameras to a single adapter. Exceeding the capacity may cause excessive heat generation or fire.

Securely plug the power cord into the power source. An insecure connection may cause a fire.

When installing the camera, fasten it securely and firmly. A falling camera may cause personal injury.

Do not install in a location subject to elevated temperature, low temperature, or high humidity. Doing so may cause fire or electric shock.

Do not place conductive objects (e.g. screwdrivers, coins, metal items, etc.) or containers filled with water on top of the camera. Doing so may cause personal injury due to fire, electric shock, or falling objects.

Do not install in humid, dusty, or sooty locations. Doing so may cause fire or electric shock.

Do not install near any heat sources such as radiators, heat registers, or other products (including amplifiers) that produce heat.

Keep out of direct sunlight and heat radiation sources. It may cause a fire. 6. 8. 9.

- Keep out of direct sunlight and heat radiation sources. It may cause a fire.

 If any unusual smells or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock. If this product does not operate normally, contact the nearest service center. Never disassemble or change this product in any way.

 When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock. 14.
- electric shock CAUTION
- Use proper safety gear when installing and wiring the product.

 Do not drop objects on the product or apply strong shock to it. Keep away from a location subject to excessive vibration or magnetic interference. Do not use this product near water.

 The product shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the product. Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the 5.
- image sensor. The Main plug is used as a disconnect device and shall stay readily operable at any time. 6.
- damage to the product.

 Do not block any ventilation openings. Install following the manufacturer's instructions.

 A polarized or grounding-type plug is recommended for this product. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. If the provided plug does not fit into your outlet, consult an electrician for replacement.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.

If any laser equipment is used near the product, make sure the surface of the sensor is not exposed to the laser

- beam as that may damage the sensor module.

 If you want to move the already installed product, be sure to turn off the power and then move or reinstall it.

 Proper configuration of all passwords and other security settings is the responsibility of the installer and/or 12. 13.
- end-user. fi cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.

 Do not touch the camera's lens or sensor module with fingers. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt. 15.
- Use only attachments/accessories specified by the manufacturer.

 Always use hardware (e.g. screws, anchors, bolts, locking nuts, etc.) compatible with the mounting surface and of sufficient length and construction to ensure a secure mount. Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product. Unplug this product when a cart is used. Use caution when moving the cart/product combination to avoid injury from tip-over. 20. Refer all servicing to qualified service personnel. Servicing is needed when the product has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.
- STEP 1 PREPARING TO MOUNT THE CAMERA
- CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock do not perform any servicing other than that contained in

This product is intended to be supplied by a UL Listed Power Supply Unit marked "Class 2" or "LPS" or "PS2" and rated 12 Vdc, 0.54A (DWC-MB75Wi4TDMP) and 0.38A (DWC-

802-3af shall be a UL Listed device with the output evaluated as a Limited Power Source as

3. The wired LAN hub providing power over the Ethernet (PoE) in accordance with IEEE

such, associated Ethernet wiring shall be limited to inside the building. 5. Using the mounting template sheet or the camera itself, mark and drill the necessary holes in

defined in UL60950-1 or PS2 as defined in UL62368-1.

Pass the wires through and make all necessary connections.

the operating instructions unless you are qualified to do so.

MB72Wi4TDMP) min.

the wall or ceiling.

Ethernet cable.

STEP 2 - POWERING THE CAMERA

4. Unit is intended for installation in a Network Environment 0 as defined in IEC TR 62102. As

Use a PoE Injector (required. Sold Use non-PoE Switch to connect data separately) to connect data and using and Ethernet cable and use a power to the camera using a single power adapter to power the camera.

Power consumption

DC12V: max 6.5W

DC12V: max 4.5W

™ 5 5Ø

PoE: max 8.3W


PoE: max 6.0W

OR


Part number **Power requirements**

ᅒ

DC 12V, PoE IEEE 802.3af Class 3 DWC-MB75Wi4TDMP (Adapter not included). DC 12V. PoE IEEE 802.3af Class 2 DWC-MB72Wi4TDMP (Adapter not included).



4.5∅



Mount the camera to the mounting surface and secure using the screws and anchors

2. Loosen the pan and tilt screws at the base of the camera's bracket to adjust the camera's

3. Remove the protective film from the lens cover. Softly wipe the dome/lens cover with

lens tissue or a microfiber cloth with ethanol to remove any dust or smudges left from the installation process.

view and position.

0=

- 0 Pan / tilt screw
- Mounting Template
- camera control. Resetting the camera: Press the reset button for five (5) seconds will initiate a camera-

NOTE: Please refer to DMP guide for additional information on integration and

Tel: +1 (866) 446-3595 / (813) 888-9555 Technical Support Hours: 9:00AM - 8:00PM EST, Monday through Friday

wide reset of all the settings, including network settings.

> digital-watchdog.com $\label{eq:copyright} \ \textcircled{o} \ \ \text{Digital Watchdog. All rights reserved.}$ Specifications and pricing are subject to change without notice.

Reset button

NOTE: Please see the full product manual for web viewer setup, functions and camera settings options. NOTE: This products is covered by one or more claims of the HEVC Patents listed at patentlist.accessadvance.com.

Rev: 05/23